

Battery	Nav Lts	Fuel Pump	Left Mag	Starter	Rt Mag	Alt	G3i	Avionics	Landing Lights
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

Fuel Pump	Pilot Heat	Low Oil Pressure	Low Voltage	Starter Engage	Pilot Door Unsafe	CuPilot Door Unsafe	Parking Brake
ON	ON	Pressure	Voltage	Engage	Unsafe	Unsafe	Brake

Warning Lights

Dim Bright

GEAR

TEST

RESET

Panel Lights

Dim Bright

Overhead Lights

Dim Bright

Fan

Low High

Outside Air

Open Closed

Warm Air

Outside Inside

Strobes	Pilot Heat	All Lights	Auto Pilot Power	Auto Pilot Engage	Fuel Pump Battery	Fuel Pump VPX
OFF	OFF	OFF	OFF	OFF	Battery	VPX

Gemini

Com1	Com2	GPS	Xponder	EFIS
OFF	OFF	OFF	OFF	OFF
Hydraulic Pump	Fuel Pump	Ground Power		
25	5	2		